



# Adaptor



<p><b>K306A</b> 1/4" MONO PLUG TO 3.5mm MONO JACK <b>K306C</b> 1/4" MONO PLUG TO 3.5mm STEREO JACK</p> 	<p><b>K306F</b> 1/4" MONO PLUG TO 3.5mm MONO JACK <b>K306G</b> 1/4" MONO PLUG TO 3.5mm STEREO JACK</p> 
<p><b>K306B</b> 1/4" STEREO PLUG TO 3.5mm STEREO JACK <b>K306D</b> 1/4" STEREO PLUG TO 3.5mm MONO JACK</p> 	<p><b>K306J</b> 1/4" STEREO PLUG TO 3.5mm STEREO JACK <b>K306H</b> 1/4" STEREO PLUG TO 3.5mm MONO JACK</p> 
<p><b>K306E</b> 1/4" MONO PLUG TO 1/4" STEREO JACK</p> 	<p><b>K306K</b> 1/4" MONO PLUG TO 1/4" STEREO JACK</p> 
<p><b>K306W</b> 1/4" STEREO PLUG TO 1/4" MONO JACK</p> 	<p><b>K306N</b> 1/4" STEREO PLUG TO 1/4" MONO JACK</p> 
<p><b>K307K</b> 3.5mm MONO PLUG TO 3.5mm STEREO JACK</p> 	<p><b>K307E</b> 3.5mm MONO PLUG TO 3.5mm STEREO JACK</p> 
<p><b>K307M</b> 3.5mm STEREO PLUG TO 3.5mm MONO JACK</p> 	<p><b>K307F</b> 3.5mm STEREO PLUG TO 3.5mm MONO JACK</p> 
<p><b>K307A</b> 3.5mm MONO PLUG TO 1/4" MONO JACK <b>K307C</b> 3.5mm MONO PLUG TO 1/4" STEREO JACK</p> 	<p><b>K307N</b> 3.5mm MONO PLUG TO 1/4" MONO JACK <b>K307P</b> 3.5mm MONO PLUG TO 1/4" STEREO JACK</p> 
<p><b>K307B</b> 3.5mm STEREO PLUG TO 1/4" STEREO JACK <b>K307D</b> 3.5mm STEREO PLUG TO 1/4" MONO JACK</p> 	<p><b>K307R</b> 3.5mm STEREO PLUG TO 1/4" STEREO JACK <b>K307S</b> 3.5mm STEREO PLUG TO 1/4" MONO JACK</p> 
<p><b>K308A</b> 2.5mm MONO PLUG TO 3.5mm MONO JACK <b>K308B</b> 2.5mm MONO PLUG TO 3.5mm STEREO JACK</p> 	<p><b>K308G</b> 2.5mm MONO PLUG TO 3.5mm MONO JACK <b>K308H</b> 2.5mm MONO PLUG TO 3.5mm STEREO JACK</p> 