



















RCA Phono Jack



K365 CHASSIS MOUNT PHONO JACK  COLOR : RED, BLACK, YELLOW, GREEN, BLUE, WHITE 	K366J RCA PHONO JACK   
K365A RCA PHONO JACK  	K366L RCA PHONO JACK  
K366 RCA PHONO JACK  COLOR : RED, BLACK, YELLOW, GREEN, BLUE, WHITE 	K366M RCA PHONO JACK  
K366A RCA PHONO JACK  COLOR : RED, BLACK, YELLOW, GREEN, BLUE, WHITE 	K366N RCA PHONO JACK  
K366D RCA PHONO JACK  	K366S RIGHT ANGLE RCA PHONO JACK   
K366E RCA PHONO JACK  	K366T RIGHT ANGLE RCA PHONO JACK   
K366F RCA PHONO JACK  	K366V RIGHT ANGLE RCA PHONO JACK (GOLD PLATED)  
K366G RIGHT ANGLE RCA PHONO JACK   	K366W RIGHT ANGLE 2P RCA PHONO JACK   
K366H RIGHT ANGLE RCA PHONO JACK   