

## USB Adapter & Gender Changer



<b>ZPAMAM (ZUAMAM)</b> USB/A TYPE MALE TO A TYPE MALE	<b>ZPE4FF</b> IEEE 1394 GENDER CHANGER 4F TO 4F <b>ZPE6FF</b> IEEE 1394 GENDER CHANGER 6F TO 6F
<b>ZPAFAF (ZUAFAF)</b> USB/A TYPE FEMALE TO A TYPE FEMALE	<b>ZPE46 MM/MF/FM</b> IEEE 1394 GENDER CHANGER 4P TO 6P
<b>ZPAMBF (ZUAMBF)</b> USB/A TYPE MALE TO B TYPE FEMALE	<b>ZPA15MF</b> DVI ANALOG TO VGA HD15
<b>ZPBMBM (ZUBMBM)</b> USB/B TYPE MALE TO B TYPE MALE	<b>ZPDA15 MM/MF/FF</b> DVI DIGITAL / ANALOG TO VGA HD15
<b>ZPBFAF (ZUBFAF)</b> USB/B TYPE FEMALE TO A TYPE FEMALE	<b>ZPDHMF</b> DVI MALE TO HDMI FEMALE
<b>ZPAFBM (ZUAFBM)</b> USB/A TYPE FEMALE TO B TYPE MALE	<b>ZPDHFM</b> DVI FEMALE TO HDMI MALE
<b>ZPBFBF</b> USB/B TYPE FEMALE TO B TYPE FEMALE	<b>ZPV MM/FF</b> V.35 GENDER CHANGER
<b>ZPAM6J</b> USB/A TYPE MALE TO MINI DIN 6P JACK	<b>ZPV25 MM/FF</b> V.35 TO DB25 GENDER CHANGER