



MANTECH[®]
ELECTRONICS

International Components Distributor

TEL JHB : (011) 493-9307

CAPE : (021) 535-3150

KZN : (031) 309-7692

FAX : (011) 493-9319

sales@mantech.co.za

www.mantech.co.za

SENTRY RECEIVERS - SETUP INSTRUCTIONS

1 Channel DIP switch Version

Operation Power - 12V to 24V AC or DC connected as per PCB legend

Coding To operate with 1 button transmitter: -
-Set switches 1 to 12 as per transmitter

To operate with 3 button transmitter: -
-Set switches 4 to 12 as per transmitter.
-Set switches 1 to 3 off.
-Set switch 1 on to operate with 1st button
-Set switch 2 on to operate with 2nd button
-Set switch 3 on to operate with 3rd button

Code Learning Versions

Operation Power - 12V to 24V AC or DC. Connected as per PCB legend

Latch operation – Place jumper on required channel pins

Pulse operation – Remove jumper from required channel pins

Coding

1. Momentarily short "Program" pins
2. LED will flash indicating channel to be learnt.
3. Operate transmitter
4. LED will flash next channel to be learnt or 1s flash to indicate coding complete.
5. Repeat from step 3 for each channel