



## Chapter 2 Remote Controller

### 2. 1 Introduction of Remote



- POWER**: Press to turn/off .
- KODI**: Fast key to Kodi
- FF**: Press to fast forward when palying video
- Play/Pause**: Press to pause when playing video,music or photo .
- Stop**: Press to stop when playing video
- Rew**: Press to rewind when palying video
- SETUP**: Fast key to go to system setup.
- APP**: Fast key to go to android application.
- VOL-** **VOL+**: Press to increase/decrease the volume.
- HOME**: Fast key to go back to main menu.
- RETURN**: Press to return back to previous menu.
- Navigation**: Press to navigate left/right/up/down.  
Press OK to confirm your choice.
- MENU**: Press to choose function menu of corresponding application in video, music, photo and website.
- Mouse**: Fast key to go back to mouse .
- Number keypad 0-9**: Press to input Arabic number.
- MUTE**: Press to turn down the volume.
- Backspace**: Press to back.

## Chapter 3 System Connection

### 3. 1 AV Connection

### 3. 2 HDMI Connection

