B169E
PUSHBUTTON SWITCH
250V 0.2A (SPST)
CLOSE TYPE



B16925A /B
4P ILLUMINATED PUSHBUTTON SWITCH (W/LED/3VDC)
125V 3A / 250V 1.5A (DPST)

A-OPEN AND CLOSE TYPE
B-OPEN TYPE

COLOR:RED
AMBER GREEN



B169F
PUSHBUTTON SWITCH
125V 0.3A
CLOSE TYPE



B16930A /B
4P ILLUMINATED PUSHBUTTON SWITCH
125V 10A / 250V 6A (DPST)

A-OPEN AND CLOSE TYPE
B-OPEN TYPE

COLOR:RED
AMBER GREEN



B169FA
PUSHBUTTON SWITCH
125V 0.75A
CLOSE TYPE



B16935A /B
4P ILLUMINATED PUSHBUTTON SWITCH (W/LED/3VDC)
125V 3A / 250V 1.5A (DPST)

A-OPEN AND CLOSE TYPE
B-OPEN TYPE

COLOR:RED
AMBER GREEN



B169G
PUSHBUTTON SWITCH
125V 2A (250V 1A)
OPEN TYPE



B16937A /B
4P ILLUMINATED PUSHBUTTON SWITCH 250V 4A (DPST)

A-OPEN AND CLOSE TYPE
B-OPEN TYPE

COLOR:RED AMBER GREEN



B169K
PUSHBUTTON SWITCH
250V 4A (SPST)
OPEN TYPE



B16960A /B (B173A /B)
3P ILLUMINATED PUSHBUTTON SWITCH 12V 10A (250V 10A)
A-OPEN AND CLOSE TYPE
B-OPEN TYPE

COLOR:RED BLUE AMBER GREEN TRANSPARENT



B169N/P
SQUARE TYPE PUSHBUTTON SWITCH 250V 8A (DPST)
N-OPEN AND CLOSE TYPE
P-OPEN TYPE



B16900
2P PUSHBUTTON SWITCH
125V 6A (250V 3A)
(SPST)
OPEN TYPE



B16901A /B (B174A /B)
3P PUSHBUTTON SWITCH
125V 4A (SPDT)

B16902A /B (B1741A /B)
6P PUSHBUTTON SWITCH
125V 4A (DPDT)

A-OPEN AND CLOSE TYPE
B-OPEN TYPE



B16903A
2P PUSHBUTTON SWITCH
125V 10A / 250V 6A (SPST)
ON-OFF

B16903B
3P PUSHBUTTON SWITCH
125V 10A / 250V 6A (SPDT)
ON-ON