KS0521 Keyestudio Solar Charger Shield (Black and Eco-friendly)

Contents	
Description	
Specification	gi gi gi gi gi and and a solar Charger
Parameters	
Charging by the solar panel	
How to get started with solar panel	
Test Method	
Test Code	
Test Result	
Resources	

Description

Keyestudio solar charger shield is home to energy collector, power management and charging, a stacked shield compatible with UNO R3 control board.

On this shield, BAT interface could output 5V when connected 3.0V-4.2V rechargeable batteries. At same time, the solar charger shield can be supplied power via the USB interface and SOL AR port. Yet, when the DIP is dialed to ON end, either external batteries or USB port supplies power to UNO R₃ board.

Moreover, CH LED(red) will be on when charging the external batteries; and OK LED indicator will be on if they are fully charged.

Specification

- Output disconnect (dip switch control)
- Short circuit protection
- 5V output when battery is connected
- Continuous charging current up to 900mA
- Battery status indicator (red: charging, green: fully charged)

Shield

Micro-USB connector

Parameters

- Battery input voltage: DC 3.0-4.5V
- USB input voltage: DC 4.75-5.25V
- Solar input voltage: DC 4.8-6V
- Maximum output power (with battery): 3W (600mA@5V)
- Ripple voltage: <100mV @ 500mA
- Size: 73*51mm
- Weight: 19.2g

Charging by the solar panel

- 1.The solar panel can charge the batteries by the sunlight and incandescent lamps. It can generate electricity from ultraviolet or infrared radiation.
- 2.When the solar panel is away from incandescent light less than 20 cm, the charging efficiency is low
- 3.Adjust the angle of solar panel to receive the light mostly
- 4.Excessive contact with water or water vapor may oxidize solar panels and reduce conversion efficiency.
- 5.Tear the plastic protection film covered on solar panel please before using it.
- 6. Take care of the solar panel and avoid scratches and collisions.

How to get started with solar panel

1.Connect the batteries and solar panel to the corresponding ports.

2.Place solar panel as follows

3.Ensure the red indicator turn on, as shown below:



https://wiki.keyestudio.com/KS0521_Keyestudio_Solar_Charger_Shield_(Black_and_Eco-friendly)

4.Green indicator will be on if battery panel is fully charged.

5.After charging, install charger board on the V 4.0 control board, then it will supply power for V 4.0 board when dialing the dip switch to ON end.

Note: Solar board and battery are not included.

Test Method

Connect the VBAT pin to Ao so that we can read the data from the Ao pin. Besides, we need to solder a $O\Omega$ resistor at R7, as shown below.



Test Code

```
/*
 Solar charger shield voltage measurement example. Connect VBAT pin to analog pin A0.
 The pin measures 2.0 V when not under direct exposre to sunlight and 5V when exposed to sunlight.
 This example code is in the public domain.
 */
// These constants won't change. They're used to give names
// to the pins used:
const int analogInPin = A0; // Analog input pin that the VBAT pin is attached to
int BatteryValue = 0;
                             // value read from the VBAT pin
float outputValue = 0;
                              // variable for voltage calculation
void setup() {
    // initialize serial communications at 9600 bps:
    Serial.begin(9600);
}
void loop() {
    // read the analog in value:
    BatteryValue = analogRead(analogInPin);
    // Calculate the battery voltage value
    outputValue = (float(BatteryValue)*5)/1023*2;
    // print the results to the serial monitor:
    Serial.print("Analog value = " );
    Serial.print(BatteryValue);
    Serial.print("\t voltage =
                                ");
    Serial.print(outputValue);
    Serial.println("V ");
```

```
// wait 100 milliseconds before the next loop
// for the analog-to-digital converter to settle
// after the last reading:
    delay(100);
}
```

Test Result

An external 3.0-4.2V rechargeable battery is attached to the expansion board, and the DIP switch is dialed to the OFF end. Upload the code, and stack the solar charger shield on the V 4.0 control board. After plugging in power by USB cable, open the serial monitor and set the baud rate to 9600.

The serial monitor displays the corresponding analog value and the voltage of rechargeable battery, as shown below.

😂 сомз				×
			5mł	
Analog value = 401	velrage = 3.927			
Analog value = 401	valtags = 3.927			
Analog value = 401	valtage = 3.027			
Analog value - 402	veltage = 3 93Y			
Analog value = 402	valvags = 3.937			
Analog value = 402	veltage = 3.93%			
Amalog value = 402	valtage = 3.93V			
Analog value = 403	valtage = 3.947			
Analog value = 403	valrage = 3.04V			
Analog value = 402	valtage = 3.837			
Analog =alus = 402	valtage = 3.83V			
Analog value = 402	valtags = 3.927			
Analog value = 402	valtage = 3.93V	124		
Analog value = 402	valtags = 3.037			
Analog value = 402	valtage = 3.93V			
2 Automatil		He line ending 😔	9600 ba	ui v

Resources

https://fs.keyestudio.com/KS0521

Retrieved from "http://wiki.keyestudio.com/index.php? title=KS0521_Keyestudio_Solar_Charger_Shield_(Black_and_Eco-friendly)&oldid=32396"

This page was last edited on 7 May 2021, at 13:22.