





(AC output side)



















Features

- True sine wave output (THD<3%)
- High surge power up to 2000W
- · Temperature controlled cooling fan
- · AC output voltage and frequency selectable by DIP S.W
- No load disspation <1.5W at standby saving mode
- -25°C ~+70°C wide operating temperature
- Power ON-OFF remote control
- · Front panel indicator for operation status
- · Protections:

Input: Reverse polarity / DC low alarm / DC low shutdown / Over voltage

Output: Short circuit / Overload / Over temp.

- Battery over discharge protection (low voltage disconnect)
- · Suitable for lead-acid or li-ion batteries

(IRC1, IRC2, IRC3 accessory sold separately, please refer to: https://www.meanwell.com/webapp/product/search.aspx?prod=IRC1)

- Support RS-232 communication
- Pull handle accessory available(sold sperately)
- · Conformal coating


· Remote controller

· 3 years warranty

# Description

NTS-1200 is a 1200W highly reliable off-grid true sine wave DC-AC power inverter. Its key features include: digital design with MCU control, streamlined control circuitry that quickly responds to environmental changes and improves reliability, high quality fan with low acoustic noise, 2000W peak power, adjustable AC output voltage and frequency, -25~+70°C wide operating temperature range, complete protection features, and etc. Combined with batteries, the NTS-1200 is suitable for use in residential, commercial, marine, automobile, mine, construction site, and remote areas with no access to utility power, and the output can be used to power fans, TV, radio, phone charger, PC/laptop, lighting, induction stove, air conditioner, electromechanical tool, communication equipment, power distribution cabinet, outdoor camping equipment, marine AC power, factory equipment, and etc.

### Model Encoding



AC output socket (Type US, EU, CN, AU, UK, UN, GFCI outlet)

DC input voltage (12: 12Vdc, 24: 24Vdc, 48: 48Vdc)

AC output voltage (1: 100/110/115/120Vac, 2:200/220/230/240Vac)

Rated wattage

Series name

## Applications

- · Home and office appliance
- Power tools
- Portable equipment
- · Vehicle
- Yacht
- Off-grid solar power system
- · Wireless network
- Telecom or datacom system




## **SPECIFICATION**

MODEL NO.		NTS-1200-112	NTS-1200-124	NTS-1200-148	NTS-1200-212	NTS-1200	-224 🗆	NTS-1200-248		
MODEL NO.				= US, GFCI, UN	□ = US, GFCI, UN □ = EU, CN, AU, UK, UN					
RATED POWER(Continuous)			ER(Continuous)	1200W			1			
AC OUTPUT		OVER RATED POWER(3 Min.)								
		PEAK POWER(10 Sec.)		1800W						
			ER(30 Cycles)	2000W						
		COROL I OWER(OU Cycles)		Default setting set at 110VAC Default setting set at 23			30/// С	201/40		
		AC VOLTAGE		100 / 110 / 115 / 120V		O C W	200 / 220 / 230 / 240Va		la by DID (	2 \\/
000	JIFUI					3.44			ie by Dir v	5.44
		FREQUENCY		Default setting set at			Default setting set at 5			
				50/60Hz selectable b			50/60Hz selectable by	DIP S.W		
		WAVEFORM		True sine wave (THD<3%)						
		AC REGULATION		±3.0% at rated input voltage						
		FRONT PANEL LED		Please see page 5						
		DC VOLTAGE	<u> </u>	12Vdc	24Vdc	48Vdc	12Vdc	24Vdc		48Vdc
		VOLTAGE RAI	NGE (Typ.)	10 ~ 16.5Vdc	20 ~ 33Vdc	40 ~ 66Vdc	10 ~ 16.5Vdc	20 ~ 33Vdc		40 ~ 66Vdc
		DC CURRENT	Г (Тур.)	120A	60A	30A	120A	60A		30A
		NO LOAD	NON-SAVING MODE	15W	'		25W		'	
C IN	PUT	DISSPATION		Default disable, ≤1.	2W ~1.5W by models	@ auto detect AC outp	out load≦10W will be ch	anged to sa	aving mod	9
		(Typ.)	SAVING MODE	1.2W	1.4W	1.5W		1.4W		1.5W
		OFF MODE C	URRENT DRAW	≦1mA						
		EFFICIENCY			91%	91.5%	90%	92%		93%
		BATTERY TY		Lead Acid or li-ion	0170	31.070	0070	- 10		3370
$\overline{}$					40A*2	25A*2	100*1	40A*2		25A*2
		FUSE (INTER	,	40A*4		25A"2 44±1Vdc				44±1Vdc
		1.04	ALARM	11±0.3Vdc	22±0.5Vdc			$22 \pm 0.5 \text{Vdc}$		
	5	LOW	SHUTDOWN	10±0.3Vdc	20±0.5Vdc	40±1Vdc		$20 \pm 0.5 \text{Vdc}$		40±1Vdc
	INPUT		RESTART	12.5±0.3Vdc	25±0.5Vdc	50 ± 1Vdc		25±0.5Vdc		50±1Vdc
	2		ALARM	15.5±0.3Vdc	31±0.5Vdc	62±1Vdc		$31\pm0.5$ Vdc		62±1Vdc
z	_	HIGH	SHUTDOWN	16.5±0.3Vdc	33±0.5Vdc	66±1Vdc	16.5±0.3Vdc	$33 \pm 0.5 \text{Vdc}$	;	66±1Vdc
PROTECTION			RESTART	15±0.3Vdc	30±0.5Vdc	60±1Vdc	15±0.3Vdc	$30 \pm 0.5 \text{Vdc}$	;	60±1Vdc
E		BAT. POLARI	TY	By internal fuse open						
품		OVER TEMPE	RATURE	Protection type: Shut down o/p voltage, re-power on to recover						
	5	OUTPUT SHORT		Protection type: Shut down o/p voltage, re-power on to recover						
	OUTPUT			105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec.						
		OVER LOAD (Typ.)		Protection type : Shut down o/p voltage, re-power on to recover						
	AC	CIRCUIT BREAKER								
		(ONLY FOR "GFCI" AC SOCKET)  GFCI PROCTECTION		15A 10A						
				UL458 (Only for "GFCI"	"AC socket, by request	) None				
		REMOTE	CONNECTOR	Power ON-OFF remo	ote control by front pa	anel dry contact connec	tor(by RELAY), Open : N	Normal work	; Short : F	Remote off
UNC	TION	CONTROL	ACCESSORY	Remote controller sold separately, Order No.: IRC1,IRC2,IRC3						
		RS-232 COM	MUNICATION	RS-232 ~ RJ11 Type	connector (Please re	efer to page 4 for more	details)			
		WORKING TE	MP.	-25 ~ +70°C (Refer to						
		WORKING HUMIDITY		20% ~ 90% RH non-c	0 /					
NVIRO	NMENT	STORAGE TEMP., HUMIDITY			-158°F, 10 ~ 95% RH	non-condensing				
		VIBRATION				-				
		VIDRATION		10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes  CR IFC62368-1 Dekra RS FN/FN62368-1 III 458 F13 FAC TP TC 004 AS/NZS 62368 1 approved						
		SAFETY STA	NDARDS		CB IEC62368-1,Dekra BS EN/EN62368-1,UL458, E13,EAC TP TC 004,AS/NZS 62368.1 approved (Please refer to next page "AC output socket" table for more details)					
		WITHSTAND	VOLTAGE	,	o next page: AC output socket -table for more details)  P:3.0KVac - AC O/P - FG:1.5KVac					
		MILITATION	VOLIAGE		Standard	1.011.700			Took Lo	vel / Note
				Parameter		140 only/ownest for Town	o LINI)		Class A	ACI / MOTE
				Radiated		148 only(expect for Type	<u>'</u>	LINIV		
		EMC EMISSION	)N	11			4,248 only(expect for T	ype-UN)	Class A	
				Harmonic Current	BS EN/EN61000					
AFE				Voltage Flicker	BS EN/EN61000	1-3-3				
& EM				BS EN/EN55024, B				1_		
Note				Parameter	Standard			Test Lev		
		EMC IMMUNI	TY	ESD	BS EN/EN61000			· ·		evel 2, 4KV conf
				Radiated	BS EN/EN61000	1-4-3		Level 2, 3	3V/m	
				Magnetic Field	BS EN/EN61000	1-4-8		Level 1, 1	1A/m	
		MTBF		198.9K hrs min. Telcordia TR/SR-332 (Bellcore); 62.0K hrs min. MIL-HDBK-217F (25°C)						
THE	RS	DIMENSION		333*184*70mm (L*W*H)						
		PACKING		3.3Kg; 2pcs/ 7.6Kg/	1.25CUFT					
			AC regulation a			load at 12.5Vdc/25V	dc/50Vdc input voltag	е.		
NOTE		2.All parame 3.The power EMC direct (as available	eters not specifier r supply is consider ctives. For guidar ole on http://www	ed above are measur dered as an indepen- nce on how to perfor v.meanwell.com)	ed at rated load, 25 dent unit, but the fir m these EMC tests	o°C of ambient temper nal equipment still nee , please refer to "EMI	rature and set to factored to re-confirm that the testing of component	ry setting. ne whole sy power sup	plies."	nplies with the
		× Product L	iadility discialme	e . Foi detailed info	mation, piease refe	er to ritips://www.mea	nwell.com/serviceDisc	лаппег.asp	X	
					, p.0400 1010			·		-1200-SPEC



#### ■ AC Output Socket MODEL NO. NTS-1200-112 NTS-1200-124 NTS-1200-148 NTS-1200-212 NTS-1200-224 NTS-1200-248 00 0 -T ₿ ald 0 Socket type TYPE-US TYPE-GFCI TYPE-UN TYPE-EU TYPE-CN TYPE-UK TYPE-AU TYPE-UN Standard Optional Standard Standard Standard Optional Optional Standard Country USA USA UNIVERSAL AUSTRALIA UNIVERSAL **EUROPE** CHINA U.K CB (E<sub>13</sub>) CB F© CB F© E<sub>13</sub> [H[ ERI C€ CB (E13) DEKRA None DEKRA Certificate c (U) us DEKRA (€ EHE






### ■ IRC1/2/3 Remote Controller (Accessory sold seperately)

- IRC1/IRC2/IRC3 is the monitoring and control unit.
- IRC1/IRC2/IRC3 can decode the RS-232 signals sent by the inverter series and display through digital meters. Note: Part of the control signals will not function properly due to different compliance of each model.








X Please refer to for more detail: https://www.meanwell.com/webapp/product/search.aspx?prod=IRC1

#### ■ Support RS-232 Communication

• The internal data of single NTS-1200 can be set or read through RS-232.



Personal Computer


\* Please refer to for more detail: http://www.meanwell.com/manual.html

#### ■ Remote ON-OFF Control (Built-in)

Remote ON-OFF	AC Output Status	
Open	power inverter ON	
Short	power inverter OFF	

#### ■ AC Output Voltage、Frequency、Power saving mode selectable by DIP SW

Output voltage and frequency setting factory settings are either 110Vac/60Hz or 230Vac/50Hz, users are able to adjust the voltage and frequency, through the DIP switch of position 1,2,3,4 on the panel.



Type-US

AC Output Voltage、 Frequency、 Power saving mode selectable by DIP SW							
SW1	SW1 SW2 SW3 SW4						
OFF	OFF: 100Vac or 200Vac	ON . FOLL-	ON - Coving mode				
OFF	ON: 110Vac or 220Vac	ON:50Hz	ON: Saving mode				
ON	OFF: 115Vac or 230Vac	OFF: 60Hz	OFF: Non-Saving mode				
ON	ON: 120Vac or 240Vac	OFF. 00HZ	Of 1. Non-Saving mode				



## ■ LED STATUS

#### Normal work:

	Green	Orange	Red	
Status	<ul><li>Inverter OK</li></ul>	Remote off Saving mode	Abnormal Status     (See below table)	

	Green	Orange	Red
	● 12.5~15.5Vdc	● 11~12.5Vdc	<11Vdc or >15.5Vdc
DC Input	• 25~31Vdc	22~25Vdc	<22Vdc or >31Vdc
	• 50~62Vdc	• 44~50Vdc	● <44Vdc or >62Vdc

	Green	Orange	Red
Load	<40% load	• 40~80% load	● >80% load


#### Abnormal status:

LED Indicator	Abnormal Indication
Status  DC Input  Load	Output overload or AC output short circuit
Status  DC Input  Load	Abnormal DC voltage
Status  DC Input  Load	Over temperature or Fan lock
Status ————————————————————————————————————	Inverter fail

Light

O Light off





### R.C Connector: JST B-XH or equivalent

Remote Control	Mating Housing	Terminal	
Pin 1,2 Open: Normal work	JST XHP	JST SXH-001T	
Pin 1,2 Short: Remote off	or equivalent	or equivalent	

#### Remote port connector (RJ11)



Assignment	Rx	GND	Tx
Remote port	2	3	4
DB9	3	5	2




# ■ Accessory List


 $\frak{\%}$  Pull handle (Optional accessory, Power inverter and Pull handle should ordered seperately)

MW's Order No.			Quantity	
	1	Pull handle		1
NTS-Handle	NTS-Handle ② Foot pa  ③ Screw	Foot pad		4
		Screw		2





## ② Foot pad






## **■ TYPICAL APPLICATION**



- 1 Battery Bank
- 2 Off-Grid DC/AC Solar Inverter (NTS series)
- 3 AC Outlet





- 1 AC/DC Battery Charger (PB/NPB/NPP series)
- 2 Battery Bank
- 3 Off-Grid DC/AC Inverter (NTS series)
- 4 AC Outlet

# ■ INSTALLATION MANUAL

Please refer to : http://www.meanwell.com/manual.html