

SPECIFICATION



Features:

- True sine wave output (THD<3%)
- High surge power up to 3000W
- U.P.S. mode and energy saving mode (selectable)
- High efficiency up to 91%
- Power ON-OFF switch
- Standby saving mode can be selectable
- Front panel indicator for operation status
- Thermostatically controlled cooling fan
- Protections: Bat. low alarm / Bat. low shutdown / Over voltage / Over temp. / Output short / Input polarity reverse / Overload / AC circuit breaker
- Application: Home appliance, power tools, office and portable equipment, vehicle and yacht...etc.
- Built-in solar / AC charger
- Optional monitoring software
- 3 years warranty



	RATED POWER (Typ.)	1500W				-		
	MAXIMUM OUTPUT POWER (
		Typ.) 1725W for 180 sec.	1725W for 180 sec. / 2250W for 10 sec. / surge power 3000W for 30 cycles					
			Factory setting set at 110VAC Factory setting set at 230VAC					
ОИТРИТ	AC VOLTAGE	100 / 110 / 115 / 120	100 / 110 / 115 / 120VAC selectable by setting button S.W			200 / 220 / 230 / 240VAC selectable by setting button S.W		
	FREQUENCY	60±0.1Hz 50/60H	60±0.1Hz 50/60Hz selectable by setting button S.W 50±0.1%Hz 50/60Hz selectable by setting button S.W					
	WAVEFORM	True sine wave (TH	True sine wave (THD<3%) at rated input voltage				·	
	AC REGULATION (Typ.)	±3.0%						
	TRANSFER TIME (Typ.)	10ms inverter b	10ms inverter by pass					
	SAVING MODE (Typ.)		Load ≤5W will be changed to standby mode					
	FRONT PANEL INDICATOR	R Battery voltage leve	Battery voltage level, output load level, saving mode, fault and op			operation status		
INPUT	BAT. VOLTAGE	12V	24V	48V	12V	24V	48V	
	VOLTAGE RANGE (Typ.)N	1	21 ~ 30VDC	42 ~ 60VDC	10.5 ~ 15VDC	21 ~ 30VDC	42 ~ 60VDC	
		ote.5 150A	75A	37.5A	150A	75A	37.5A	
	NO LOAD DISSIPATION	≤18W @ standby			100/1	1071	01.6/1	
	OFF MODE CURRENT DRA							
		ote.2 87%	89%	90%	88%	90%	91%	
	BATTERY TYPES	Open & sealed Lea		30 /0	00 /0	JU 70	J 1 /0	
	FUSE	40A*5	30A*3	30A*2	40A*5	30A*3	30A*2	
BATTERY INPUT PROTECTION	BAT. LOW ALARM	11.3±4%	22.5±4%	45±4%	11.3±4%	22.5+4%	45±4%	
	BAT. LOW SHUTDOWN	10.5±4%	21±4%	43±4% 42±4%	10.5±4%	21±4%	43 <u>+</u> 4%	
	REVERSE POLARITY	By internal fuse ope	11	4 ∠ <u>4</u> 70	10.524 /0	∠ 1 ≐4 /0	72.77	
OUTPUT PROTECTION	OVER TEMPERATURE	-		06°0 + 5°0	C0°C + 5°C	60°C + 5°C	C0°C + 5°C	
			82°C±5°C 82°C±5°C 96°C±5°C 68°C±5°C 68°C±5°C 68°C±5°C					
	OUTDUT CHOST	• • • • • • • • • • • • • • • • • • • •	Protection type: Shut down o/p voltage, re-power on to recover; by internal RTH3 detect on heatsink of power transistor					
	OUTPUT SHORT		Protection type: Shut down o/p voltage, re-power on to recover					
	OVER LOAD (Typ.)		105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec.					
			Protection type : Shut down o/p voltage, re-power on to recover					
	CIRCUIT BREAKER	-	20A			10A		
	GFCI PROCTECTION		Optional (Only type F)			None		
ENVIRONMENT SAFETY & EMC								
	WORKING HUMIDITY		20% ~ 90% RH non-condensing					
	STORAGE TEMP., HUMIDI		-30 ~ +70°C / -22 ~ +158°F, 10 ~ 95% RH					
	VIBRATION		10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes					
	SAFETY STANDARDS	, -	UL458 (only for "GFCI" receptacle-Type F) None					
	LVD		None EN60950-1					
	WITHSTAND VOLTAGE		=======================================			/P - FG:1.5KVAC		
	EMI CONDUCTION&RADIAT		Compliance to FCC class A			Compliance to EN55022 class B, 72/ 245/ CEE, 95/ 54/ CE, E-N		
	EMS IMMUNITY	None				Compliance to EN61000-4-2,3,4,5,6,8,11		
AC	CHARGE CURRENT (Typ.)		2.7A	1.35A				
CHARGER	CHARGE VOLTAGE	14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%	57V±4%	
SOLAR CHARGER	MAX OPEN CIRCUIT VOLTA		45V	75V	25V	45V	75V	
	CHARGE CURRENT (max.	<i>'</i>						
	CHARGE VOLTAGE	14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%	57V±4%	
OTHERS	CONTROL WIRING	RJ11 -RS232 (Option	RJ11 -RS232 (Option)					
	DIMENSION	,	420*220*88mm (L*W*H)					
	PACKING	6.85Kg; 2pcs/14.7k	•					
NOTE	3.Output derating capaci 4.All parameters not spe	1000W, linear load at 1 ty referenced by curve cified above are measure.	DW, linear load at 13V, 26V, 52V input voltage.					



■ Instructions for TN-1500 monitoring software

1. Installation of TN-1500 unit and PC




Figure 1

2. Explanation of Monitoring Manu

2.1 Main Page




Figure 2

- 1. Setting: Adjustment for output voltage, charging related voltage, frequency, and operation mode. Please refer to Figure 3 for details.
- 2. Statistics: Calculate for the percentage of operating period for each operation mode. Please refer to Figure 4 for details.
- 3. R.C. Power off: Power can be turned ON or OFF at the remote location.
- 4. Pause: Stop refreshing the page of monitoring software.
- 5. Status of unit: Indicating current operating status of TN-1500.
- 6. Signals that display current condition of the unit.



2.2 Setting Page




Figure 3

- 1. User can adjust the settings based on the characteristics of batteries been used: Equalization Voltage, Floating Voltage, Alarm Voltage, and Shut-down Voltage. UPS Mode / Energy Saving Mode selection and AC output voltage and frequency can also be set in this page.
- 2. Read: Read current settings of the unit.
- 3. Write: Write the revised setting into the unit.
- 4. Load: Load in factory default settings.

2.3 Statistic Page




Figure 4

- 1. Start Date: Date that installing the monitoring software.
- 2. Reset Date: Date that resetting the statistics. The Start Date will not be influenced by resetting the statistics or turning off the unit.
- 3. Inverter time rate: Operating period of "Inverter Mode" represents how many percent of the whole operating period.
- 4. Bypass time rate: Operating period of "Bypass Mode" (energy provides directly by the utility) represents how many percent of the whole operating period.
- 5. Shut down rate: Percentage of time period that the unit is under the condition of shut down.
 - * Inverter time rate + Bypass time rate + Shut down rate = 100%
- 6. Solar time rate: Percentage of time period that the solar charger is functioning after turning on the TN-1500 unit.
- 7. Loading average: Average loading after turning on the TN-1500 unit.



